

TROUBLE SHOOTING

ELECTRONIC CIRCUIT BOARDS FUSE - MAIN CIRCUIT BOARD

The main circuit board is protected by a fuse. If this fuse should blow it will isolate the whole machine. The correct replacement fuse is a slow blow HRC Ceramic. Refer parts list for correct size.

DO NOT USE GLASS TYPE FUSES

When changing circuit boards ensure that:

- (a) The incoming active goes to the relay tab marked COM.
- (b) The ribbon cable connecting the two boards is correctly orientated, i.e. red cable on top of main circuit board and on bottom of the control board.